



Engraving Jig Instructions for: *The Personalised Touch* KEY15 Heart Keyring

***ALWAYS ensure the Centre Origin Point is correct before engraving.**
User's Manual Page 76 and C:\Program Files\METAZASTudio\Samples\Axis.mzs



1. Ensure the Master Jig is screwed down securely with the deep ledge facing the centre.
2. Place the Heart Keyring as central as possible in the recess of the ledge after removing the keyring's split ring.



3. Open "M-JIG_KEY15.mzs" MZS Template found on the Metaza.com CD or website.
4. Import Image/Text/Logo and proceed to engrave following the MPX-80's User Manual.

This item CAN be engraved without using the green protective nose cone.

See page 32 of User's Manual or Metaza.com website.

Please note that different materials require different Brightness/Contrast/Gamma levels within PrintPreview mode.